

TECHNICAL SERVICE

VeriCore™ with
ProGen™ Rigid Core Technology

Product Specification

VeriCore™ flooring can be installed in Residential, Light-Commercial and 3-Season Room applications by following the recommendations outlined in the Tarkett VeriCore™ Installation Instructions on the detailed carton instructions or at www.menards.com.



1. PRODUCT DETAILS

- **Nominal Thickness:** 0.197" (5 mm)
- **Core Thickness:** 0.157" (4 mm)
- **Accoustical Backing:** 0.039" (1mm) IXPE
- **Wearlayer Thickness:** 0.020" (.51 mm)
- **Edge Treatment:** Microbeveled

	7"x48" 178mm x 1220 mm
Number of Styles	4
Square Feet per Carton	19.05 (1.77m ²)
Planks per Carton	8
Cartons per Pallet	75
Lbs. per Carton	32

2. PRODUCT PERFORMANCE AND TECHNICAL DATA

- 2.1. **Dimensional Stability:** ASTM F2199: Passes
- 2.2. **Heat Stability:** ASTM 1514: $\Delta E \leq 8$
- 2.3. **Light Stability:** ASTM F1515: $\Delta E \leq 8$
- 2.4. **Residual Indentation :** ASTM F1914: Passes
- 2.5. **Stain Resistance:** ASTM F925: Passes
- 2.6. **Impact Sound:** ASTM E2179: $\Delta IIC \geq 21$ dB
- 2.7. **Slip Resistance:** ASTM D2047: SCOF ≥ 0.5
- 2.8. **Fire Performance:** ASTM E648: ≥ 0.45 w/cm²
- 2.9. **FloorScore® Certification:** SCS-EC10.3-2014 v3.0

3. INSTALLATION – Refer to Carton for Detailed Installation Instructions or visit www.menards.com.

- Maintain the work area between 55° F and 95° F (12°C - 35°C) for 48 hours before, during, and after installation. Refer to Installation Instructions for complete details regarding applications with and without permanent HVAC controls.
- Cartons shall be stored horizontally on a sturdy base at all times.

4. WARRANTY – See Carton for complete details, or contact Tarkett Technical Services at (888) 639-8297.

- LIFETIME RESIDENTIAL LIMITED WARRANTY
- 20-YEAR COMMERCIAL WEAR LIMITED WARRANTY
- 5-YEAR 3-SEASONS ROOM LIMITED WARRANTY

5. MAINTENANCE

- 5.1. Furniture can be replaced immediately after installation.
- 5.2. Never slide heavy furniture or appliances across the floor. Place sheets of plywood over finished floor when moving furniture and appliances into position.
- 5.3. Use non staining mats or area rugs at doorways and entranceways to collect excess water, sand, grit and debris. Clean the mats and area rugs on a regular basis.
- 5.4. Use smooth, hard plastic or metal furniture rests or glides under frequently moved furniture to avoid scratches and indentations. Do not use felt pads.
- 5.5. Clean floor using a neutral pH floor cleaner. Follow manufacturers label instructions for precaution and use.

7. TECHNICAL SERVICES

For current Installation and Maintenance Instructions, Product Specifications, and other technical data, visit www.tarkettna.com or www.menards.com or contact Tarkett at (888)-639-8297.